




RAJA SEALS®

RS OPS TYPE TYPICAL INSTALLTION AND DIMENSION



PART CODE	D1	D2 ± 0.05	D3 ± 0.50	D4 Min.	D5	L1	L2	L3
RS14 OPS	14	31.50	31.50	34.50	18.00	9.50	10.00	30.50
RS15 OPS	15	29.50	31.50	34.50	18.00	7.50	7.50	22.50
RS16 OPS	16	31.50	31.50	34.50	18.00	9.50	10.00	35.50
RS16 OPS-01	16	30.00	31.50	34.50	18.00	8.00	7.80	29.30
RS16 OPS-02	16	30.00	31.50	34.50	18.00	6.50	5.90	22.00
RS19 OPS	19	34.50	35.00	38.00	21.00	9.25	9.50	35.00

- ❖ ALL DIMENSIONS ARE IN MM
- ❖ APPLY ONLY SOAP WATER ON ELASTOMER PARTS DURING INSTALLATION

www.rajaseals.com



94875 47913

REV : 11

DATE : 15-04-25